



 7 MIN READ, 11 PAGES

# Self-Serve Terminal Equipment Overview

[Self-Serve Terminal - External View](#)

[Keys to SST](#)

[Turning SST On/Off](#)

[Ticket / Voucher Scanner](#)

[Ticket / Voucher Printer](#)

- [Loading Paper](#)

[Bill Acceptor](#)

- [Emptying Cash Box](#)

[Coin Acceptor](#)

- [Emptying Coin Box](#)

SEE NEXT PAGES FOR MORE INFO



Text or Call Lottery Retail Support:  
**1-800-667-1649**





# Self-Serve Terminal

## Equipment Overview

In this information sheet, you will learn about the Self-Serve Terminal (SST) equipment features, how to open equipment doors and access cash and coin boxes

### Self-Serve Terminal External View

1. **Marketing Display**
  - Provides marketing and promotional information for Players
2. **Touch Screen Display**
  - Guides Players to purchase and validate Lottery products
3. **Payment Card Terminal**
  - Players will have the option to pay with Debit / Credit Cards
4. **Ticket / Voucher Scanner**
  - Validates Tickets or Vouchers
5. **Ticket / Voucher Printer**
  - Prints out Ticket purchase or Voucher
6. **Bill Acceptor**
  - Accepts all Canadian banknotes
7. **Coin Acceptor**
  - Accepts Canadian coins
8. **Coin Return**
  - Player's access point for returned coins
9. **Keys**
  - 3 colour-coded keys to open the Self-Serve Terminal



Text or Call Lottery Retail Support:  
**1-800-667-1649**






# Self-Serve Terminal Equipment Overview

## Keys to SST

Each Retailer will receive **3 colour coded keys** for each of the **4 locks** on the SST.

KEY LOCATION & COLOURS	
Location on SST	Key Colour
Bottom Door	Blue
Printer Door	Green
Bill Acceptor Door	Red
Coin Acceptor Door	Red

Printer Door



Bill Acceptor Door



Bottom Door



Coin Acceptor Door



### Red Keys for Management only

- Gives access to Bill Acceptor and Coin Acceptor



Text or Call Lottery Retail Support:  
**1-800-667-1649**





# Self-Serve Terminal

## Equipment Overview

### Turning On/Off Self-Serve Terminal

1. Retailer will use the **Blue** key to open Bottom Door




2. To turn the Self-Serve Terminal On or Off, use the button located on the back of the **PC Unit**

- Hold down the button until the SST Touchscreen Display and Marketing Display turn off
- Repeat steps to turn back on



PC Unit



Back of PC Unit



Text or Call Lottery Retail Support:  
**1-800-667-1649**






# Self-Serve Terminal Equipment Overview


## Ticket / Voucher Scanner

### External View



### Internal View



 Ticket / Voucher Tray



Ticket / Voucher Scanner

Validated Tickets and Vouchers **will not be kept inside the SST**. Please ensure Players dispose of Tickets when they no longer require them.



Text or Call Lottery Retail Support:  
**1-800-667-1649**





# Self-Serve Terminal


## Equipment Overview

### Ticket / Voucher Printer

#### External View



#### Internal View



Text or Call Lottery Retail Support:  
**1-800-667-1649**









# Self-Serve Terminal

## Equipment Overview

### Ticket / Voucher Printer

#### How to Load Paper Roll

1. Insert paper roll as shown and pull on the leading edge of the paper towards you
2. Pass the paper edge above the **green plastic tensioner** and insert it on the printer head rear inlet until the printer detects it. The printer will automatically pull the paper and cut a section of it. The printer is ready for use.



#### Low Paper Warning

When the paper roll is low it will trigger a **pop-up warning** on the SST and prevent the Player from creating a Ticket.



**Retailer intervention required  
printer: Paper Low**



Text or Call Lottery Retail Support:  
**1-800-667-1649**





# Self-Serve Terminal

## Equipment Overview


### Bill Acceptor

#### External View



Bill Acceptor takes \$5 - \$100 bills

#### Internal View



Text or Call Lottery Retail Support:  
**1-800-667-1649**










# Self-Serve Terminal Equipment Overview

## Emptying the Cash Box

1. Retailer will use the **RED** key to open Bill Acceptor Door



2. Press the **BLUE** Latches located on both sides of the Cash Box. Pull the Cash Box out.



3. Rotate Lock **CLOCKWISE** until in the "OPEN" position and the Lock releases



4. Open the Cash Box and retrieve cash



Follow steps **in reverse** to return the **Cash Box**. Cash Box is placed correctly when a **\*click noise\*** is heard, and unit motors begin to operate.



Text or Call Lottery Retail Support:  
**1-800-667-1649**





# Self-Serve Terminal

## Equipment Overview


### Coin Acceptor

#### External View



Coin Acceptor **only**  
takes **¢25, \$1 & \$2** coins

#### Internal View



Text or Call Lottery Retail Support:  
**1-800-667-1649**





# Self-Serve Terminal

## Equipment Overview

### Emptying the Coin Box

1. Retailer will use the **Blue** key to open Bottom Door



2. Use the **Red** key to unlock the Coin Box



3. Grab the Coin Box from its front handle and slide it out to collect coins



**PLEASE NOTE:** Make sure the Coin Box is closed and locked before closing the Bottom Door.

[PDF Read More](#)

For information on Touch Screen Display



Text or Call Lottery Retail Support:  
**1-800-667-1649**

