

Quick Reference Guide: Compact Lottery Terminal and Ticket Checker Installation

This Quick Reference Guide explains how to disconnect your old equipment and set up your new Compact Lottery Terminal and Ticket Checker. Read and follow each of the steps carefully.



Disconnecting Old Equipment (Lottery Terminal, Printer, and Ticket Checker)

Old Lottery Terminal & Printer



- 1 Locate the power button at the back near the bottom corner, and power off the Lottery Terminal.



- 2 Once the Lottery Terminal is off, unplug the white labelled cables in any order from the back of the Terminal and the Printer. The labels were added by Lotto Technicians during Pre-Installation to identify which cables you need to unplug.

- 3 Keep all the cables on the counter, a Lotto Technician will return at a future date to remove them as part of the cleanup. If any of the white labelled cables is still plugged into a power source, you can leave them as is.
- 4 Once free of all the cables, move the old Terminal and Printer to a safe location out of the way. Clean the counter space where the equipment was in preparation for your new Compact Lottery Terminal.


Old Ticket Checker



If your old Ticket Checker has been temporarily attached to the new Ticket Checker with removable cable ties, locate the provided side cutter in the Start Up Kit and cut the cable ties. You can also separate the cable ties by pulling on the unlock tab.



Follow the plug from the old Ticket Checker and remove the power cable from its power source.



Unplug the data cable from the back of the old Ticket Checker.

- 8 Move the old Ticket Checker to a safe location out of the way. If your old Ticket Checker is still firmly attached to the wall or counter, you can leave it in place unplugged from the wall outlet and a Lotto Technician will retrieve it as part of the cleanup.



Setting up New Equipment (Compact Lottery Terminal and new Ticket Checker)

Compact Lottery Terminal

- 9 Take the new Compact Lottery Terminal out of the box. Hold the Terminal at the neck or by supporting the base.

Place the Compact Lottery Terminal where the old Lottery Equipment was and remove any protective covering. Keep the box for the old equipment.



- 10 Locate the cable harness with Red, Yellow, and Green labelled cables.

11 Connect the colour-coded cables in the order listed below:



Connect the Red cable into the port with the Red dot.



Connect the Yellow cable into the port with the Yellow dot.



Connect the Green cable into the port with the Green dot.



12 Locate the power button at the back of the monitor, and turn on the Compact Lottery Terminal.

Once the Compact Lottery Terminal is powered on, the Login screen will appear. Do not attempt to log on until you have received notification from BCLC that the software update is complete and that your Lottery Terminal is ready for use.

If you attempt to log on prior to the completion of the software update, you will see an error message or there will not be any games present on the display to sell. If this occurs, ensure you are logged out of the Lottery Terminal and back at the Login screen.

New Ticket Checker

13 Remove 'Coming Soon' decal.




14 If your Ticket Checker is not powered on, power on the new Ticket Checker by pressing the power button located at the back in the upper corner.

This completes setting up your new Compact Lottery Terminal and new Ticket Checker.



Packing up Old Equipment (Lottery Terminal, Printer and Ticket Checker)



15 Remove the courier return waybill from the envelope inside the box, and then complete steps 16 to 19.

- If you DO NOT see a return waybill, pack up the equipment and a BCLC representative will pick up the old equipment in 1-3 days. You do not have to call for a pick-up.

16 Put the old Lottery Terminal, Printer and Ticket Checker into the box the new Lottery Equipment came in, and do your best to include some of the packaging to hold the old equipment from moving around in the box during shipping.



17 Use the tape provided to seal the box.



18 Place the courier return waybill over the original waybill on the box.



19 Call Purolator at 1-888-SHIP-123 (1-888-744-7123) for a pick-up.



Support

If you run into a problem, check that you have followed the steps correctly, then call 1-800-667-1649 for Lottery Retail Support.



Visit the Retailer Hub Lotto Transformation page for related training resources.



THE
FUTURE
OF PLAY.